

“JAWS” Wire Termination

For 1/4” Strand

- Make sure the (1) cap is loose enough for the strand to go completely through device. When getting started, you can remove the screws one at a time, then reinsert them slightly back into the block.
- Insert strand through the paper tape (do not remove tape) then completely through the “JAWS” device & cut off any excess - leave 1/2” past the cap screws (3)
- Tighten cap screws until the jaws start to touch the strand, then alternate tightening each screw until both are tight.
- Use a 3/16 T handle hex driver (4) to tighten the device as much as possible by hand using the method described above.

